Stratus[®] ftServer[®] V 6512: Site Planning Guide

Stratus Technologies R675-03B

Notice

The information contained in this document is subject to change without notice.

UNLESS EXPRESSLY SET FORTH IN A WRITTEN AGREEMENT SIGNED BY AN AUTHORIZED REPRESENTATIVE OF STRATUS TECHNOLOGIES, STRATUS MAKES NO WARRANTY OR REPRESENTATION OF ANY KIND WITH RESPECT TO THE INFORMATION CONTAINED HEREIN, INCLUDING WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PURPOSE. Stratus Technologies assumes no responsibility or obligation of any kind for any errors contained herein or in connection with the furnishing, performance, or use of this document.

Software described in Stratus documents (a) is the property of Stratus Technologies Bermuda, Ltd. or the third party, (b) is furnished only under license, and (c) may be copied or used only as expressly permitted under the terms of the license.

Stratus documentation describes all supported features of the user interfaces and the application programming interfaces (API) developed by Stratus. Any undocumented features of these interfaces are intended solely for use by Stratus personnel and are subject to change without warning.

This document is protected by copyright. All rights are reserved. Stratus Technologies grants you limited permission to download and print a reasonable number of copies of this document (or any portions thereof), without change, for your internal use only, provided you retain all copyright notices and other restrictive legends and/or notices appearing in the copied document.

Stratus, the Stratus logo, ftServer, the ftServer logo, Continuum, StrataLINK, and StrataNET are registered trademarks of Stratus Technologies Bermuda, Ltd.

The Stratus Technologies logo, the Continuum logo, the Stratus 24 x 7 logo, ActiveService, Automated Uptime, Active Upgrade, ftScalable, and ftMessaging are trademarks of Stratus Technologies Bermuda, Ltd.

RSN is a trademark of Lucent Technologies, Inc.

All other trademarks are the property of their respective owners.

Manual Name: Stratus ftServer V 6512: Site Planning Guide

Part Number: R675 Revision Number: 03B OpenVOS Release Number: 19.1.0 Publication Date: December 2019

Stratus Technologies, Inc. 5 Mill and Main Place, Suite 500 Maynard, Massachusetts 01754-2660

© 2019 Stratus Technologies Bermuda, Ltd. All rights reserved.

Contents

Preface	vii
1. Site Planning for ftServer V 6512 Systems	1-1
Site Planning Overview	1-1
Site Planning for Fault-Tolerant Systems	1-2
Planning for Cables	1-3
Site Planning Checklist	1-7
Preparing to Install a System	1-9
Preparing to Take Delivery of a System	1-9
Moving the System to the Installation Site	1-10
System Documentation	1-10
Safety Notices	1-11
Consignes de sécurité	1-15
2. AC Power Planning	2-1
AC Power Overview	2-1
Redundant Power Sources	2-1
AC Power and HVAC Worksheets	2-2
Selecting a UPS Unit for ftServer Systems	2-4
AC Power Connections to Qualified UPS Models	2-5
Main Cabinet Ground Cables	2-6
2. Succe Blanning and Component Location	2.4
3. Space Planning and Component Location	3-1
RSN Connections	3-1
Fibre Channel Connections	3-2
Oro Connections	<u>১-</u> ८
Component Location and Cabling Summary	<u> </u>
Routine Mounting and Lovaling Considerations	১-১ ০ ব
Capinet Mounting and Leveling Considerations	১-1 २ न
Greating a FIOOF FIAN	5-1

4. Other Infrastructure Requirements Telephone Lines Network Connections Site Ethernet Networks Ethernet Subnet Requirements Maintenance Network System PC Console	4-1 4-2 4-2 4-3 4-3 4-4
5. Supported Configurations	5-1
Cabinet Configurations	5-1
Appendix A. System Specifications	A-1
System Specifications	A-1
AAP87600V PDU Specifications	A-7
Appendix B. Electrical Circuit and Wiring Information Fault Protection Requirements Grounding Considerations Circuit Wiring Diagrams Electrical Power Connectors	B-1 B-1 B-2 B-8

Index

Index-1

Figures

Figure 1-1.	AA-E97900 RSN Console Server Connections (Internet)	1-4
Figure 1-2.	AA-E99100 Console Server Connections (Modem)	1-5
Figure 1-3.	AA-E97900 Console Server Connections (Modem)	1-6
Figure 3-1.	Space-Planning Considerations	3-7
Figure 3-2.	System Equipment Templates	3-9
Figure 3-3.	Site-Layout Grid	3-10
Figure 5-1.	Base ftServer V 6512 System	5-2
Figure 5-2.	Fully Configured ftServer V 6512 System	5-3
Figure A-1.	CPU-I/ O Enclosures: Front View	A-2
Figure A-2.	ftServer CPU-I/ O Enclosures: Rear View	A-3
Figure A-3.	AAP87600V PDU	A-7
Figure B-1.	Star Ground Example	B-2
Figure B-2.	Power Input Labeling	B-3
Figure B-3.	Single-Phase 120V AC Circuit Connection	B-3
Figure B-4.	Single-Phase 240V AC Circuit Connection	B-4
Figure B-5.	Split-Phase 120/240 Volts AC Circuit Connection	B-5
Figure B-6.	Three-Phase 208V AC, Y-, or D-Source Circuit	
	Connection, Phase-to-Phase	B-6
Figure B-7.	Three-Phase 380V AC, Y-, or D-Source Circuit	
	Connection, Phase-to-Neutral	B-7

Tables

Ethernet PCI Adapters	1-7
ftServer V 6512 System Documentation	1-10
Worksheet for Planning Site AC Outlets and Cord Lengths	2-3
Work Sheet for Site AC Power and HVAC Requirements	2-4
Power Cords for ftServer Systems	2-5
Main Cabinet Ground Cable	2-6
Cord and Cable Summary	3-3
Location of V Series System Components	3-4
Ethernet Subnet Requirements	4-3
Cabinet Dimensions	A-4
V 6512 System CPU-I/ O Enclosure: Specifications	A-5
AAP87600V PDU: Specifications	A-8
Connectors for AC Power Outlets	B-8
	Ethernet PCI Adapters ftServer V 6512 System Documentation Worksheet for Planning Site AC Outlets and Cord Lengths Work Sheet for Site AC Power and HVAC Requirements Power Cords for ftServer Systems Main Cabinet Ground Cable Cord and Cable Summary Location of V Series System Components Ethernet Subnet Requirements Cabinet Dimensions V 6512 System CPU-I/ O Enclosure: Specifications AAP87600V PDU: Specifications Connectors for AC Power Outlets

Preface

The *Stratus ftServer V 6512 System: Site Planning Guide* (R675) documents the site requirements and customer responsibilities related to preparing a site for the installation of ftServer V 6512 systems.

This document is intended for those responsible for preparing a site for the installation of ftServer V 6512 systems.

Revision Information

This manual is a revision. Change bars, which appear in the margin, note the specific changes to text since the previous publication of this manual. Note, however, that change bars are not used in new chapters or appendixes.

Changes include the following:

- Support for the AA-T53700 LTO-7 Single Tape-Drive Enclosure
- The removal of compliance information from this document. See Regulatory Notice for information about the new location of compliance information.
- · The correction of some documentation errors

NOTICE _____

Contact your account representative for information about the availability of OpenVOS 19.*x* support for the NIO enclosure.

Notation Conventions

This document uses the notation conventions described in this section.

Warnings, Cautions, and Notes

Warnings, cautions, and notes provide special information and have the following meanings:



A warning indicates a hazardous situation that, if not avoided, could result in death or serious injury.



AVERTISSEMENT _____

Un avertissement indique une situation dangereuse qui, si pas évitée, pourrait entraîner la mort ou des blessures graves.



CAUTION -

A caution indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.



MISE EN GARDE -

Une mise en garde indique une situation dangereuse qui, si pas évitée, pourrait entraîner des blessures mineures ou modérées.

NOTICE -

A notice indicates information that, if not acted on, could result in damage to a system, hardware device, program, or data, but does not present a health or safety hazard.

NOTE _____

A note provides important information about the operation of an ftServer system or related equipment or software.

Typographical Conventions

The following typographical conventions are used in this document:

• Italics introduces or defines new terms. For example:

The *master disk* is the name of the member disk from which the module was booted.

• Boldface emphasizes words in text. For example:

Every module **must** have a copy of the module_start_up.cm file.

 Monospace represents text that would appear on your terminal's screen (such as commands, subroutines, code fragments, and names of files and directories).
For example:

change_current_dir (master_disk)>system>doc

 Monospace italic represents terms that are to be replaced by literal values. In the following example, the user must replace the monospace-italic term with a literal value.

```
list users -module module name
```

• Monospace bold represents user input in examples and figures that contain both user input and system output (which appears in monospace). For example:

display_access_list system_default

%dev#m1>system>acl>system default

w *.*

Getting Help

If you have a technical question about ftServer system hardware or software, try these online resources first:

• Online documentation at the StrataDOC Web site. Stratus provides complimentary access to StrataDOC, an online-documentation service that enables you to view, search, download, and print customer documentation. You can access StrataDOC at the following Web site:

http://stratadoc.stratus.com

 Online support from Stratus Customer Service. You can find the latest technical information about an ftServer system in the Stratus Customer Service Portal at the following Web site:

http://www.stratus.com/go/support

The Service Portal provides access to Knowledge Base articles for all Stratus product lines. You can locate articles by performing a simple or advanced keyword search, viewing recent articles or top FAQs, or browsing a product and category.

To log in to the Service Portal, enter your employee user name and password or, if you have not been provided with a login account, click **Register Account**. When registering a new account, ensure that you specify an email address from a company that has a service agreement with Stratus.

If you cannot resolve your questions with these online self-help resources, and the ftServer system is covered by a service agreement, contact the Stratus Customer Assistance Center (CAC) or your authorized Stratus service representative. To contact the CAC, use the Service Portal to log a support request. Click **Customer Support** and **Add Issue**, and then complete the **Create Issue** form. A member of our Customer Service team will be glad to assist you.

If you are unable to resolve your questions with the help available at these online sites, and the ftServer system is covered by a service agreement, please contact the Stratus Customer Assistance Center (CAC) or your authorized Stratus service representative. For information about how to contact the CAC, see the following Web site:

http://www.stratus.com/go/support/ftserver/location

Commenting on This Manual

You can comment on this manual using one of the following methods. When you submit a comment, be sure to provide the manual's name and part number, a description of the problem, and the location in the manual where the affected text appears.

- From StrataDOC, click the **site feedback** link at the bottom of any page. In the pop-up window, answer the questions and click **Submit**.
- From any email client, send email to comments@stratus.com.
- From the Stratus Customer Service Portal, log on to your account and create a new issue.

Stratus welcomes any corrections and suggestions for improving this manual.

Regulatory Notice

All regulatory notices are provided in *Compliance Information for Stratus Products* (R002G), which is available on StrataDOC:

https://stratadoc.stratus.com/compliance_info/Compliance_Information_for_Strat us_Products.htm

Chapter 1 Site Planning for ftServer V 6512 Systems

For an overview of required information and tasks you need to perform to prepare a site for ftServer V 6512 systems, see:

- "Site Planning Overview" on page 1-1
- "Site Planning for Fault-Tolerant Systems" on page 1-2
- "Planning for Cables" on page 1-3
- "Site Planning Checklist" on page 1-7
- "Preparing to Install a System" on page 1-9
- "System Documentation" on page 1-10
- "Safety Notices" on page 1-11

Site Planning Overview

Site planning for fault-tolerant systems includes:

• Electrical power planning

Provide electrical power sources that meet the requirements of the system and optional components, including the purchase of a qualified uninterruptible power supply (UPS).

• Space planning

Plan the location of the system and external components to accommodate the lengths of the connecting cables.

Provide adequate space for the system or cabinet and for a desk or table to accommodate components outside a cabinet. Also provide enough space for servicing the systems and components.

Provide an environment that meets the system's requirements for ambient temperature and air quality.

• Other Infrastructure requirements

Understand Ethernet requirements. Provide sufficient network and telephone connection points.

Provide a PC to act as a system PC console. Stratus provides a serial cable for connecting the PC to the server. You must provide an Ethernet cable to connect the system PC console to the ftServer system.

Use the "Site Planning Checklist" on page 1-7 to track your site preparation progress.

For information about obtaining documents related to your ftServer system, see "System Documentation" on page 1-10.

During the site planning and preparation processes, work closely with your facilities group or contractor to determine space, power, and environmental requirements. Enlist their help to provide a suitable location with sufficient alternating current (AC) power, heating, ventilation and air conditioning (HVAC) capabilities, and network and telephone connections.

If your system is covered by a service agreement and you need help with site planning, contact the Stratus Customer Assistance Center (CAC) or your authorized Stratus service representative. If you have a contract with the CAC or your authorized Stratus service representative to install the system, contact them after you have prepared the installation site and moved the system to the site. For more information about the CAC, see Getting Help in the Preface or the http://www.stratus.com/support/cac/ Web site.

See Chapter 5 for illustrations of the rack configurations of your ftServer system and other rack-mounted components, and Appendix A, "System Specifications" for the specifications of the base ftServer systems and of PDUs. See the *Stratus ftServer Systems: Peripherals Site Planning Guide* (R582) for specifications of other components, both rack-mounted and external to the rack.

Site Planning for Fault-Tolerant Systems

Consider the following specific fault-tolerant features of ftServer systems as you plan the site:

• Lockstep technology means that the systems contain redundant hardware. The systems contain two enclosures, each containing a full computing environment that consists of a CPU element and an I/O element.

If a component in a CPU element malfunctions, the corresponding CPU element in the other enclosure, which is processing the same information in lockstep, continues processing without interruption. If a component in the I/O element malfunctions, the system fails operation over to the corresponding element in the other enclosure and continues to operate normally. The only consequences are

that the system is less fault tolerant, and any I/O throughput distributed between the enclosures may be reduced. To restore full fault tolerance, an enclosure can be replaced without taking the system offline.

• ftServer systems can connect to the Remote Service Network (RSN).

Connecting a system to the RSN allows the CAC or your authorized Stratus service representative to remotely diagnose, troubleshoot, and resolve problems online.

Your system connects to the RSN by an RSN console server connected either to the Internet or to a modem. See "RSN Connections" on page 3-1 for more information.

Planning for Cables

At sites with solid (non-raised) floors, the cables exit from the top of the cabinet and are routed along the ceiling.

At sites with raised floors, the cables exit from the bottom rear of the cabinet and are routed under the floor.

To accommodate cables from your system, make sure to provide:

- One or two telephone lines as described in "Telephone Lines" on page 4-1:
- · Ethernet ports, switches, or hubs, as needed
- Two UPS units, within reach of the power cords from the system or PDUs
- For external components, AC wall outlets within reach of the power cords from the components

Make sure that cables you plan to connect to the system are long enough to reach between the system and external components or connections. For information about specific cables and power cords, see the following:

- Chapter 3, "Space Planning and Component Location"
- Stratus ftServer Systems: Peripherals Site Planning Guide (R582) for information about cable lengths for peripheral components

Figure 1-1 shows cabling considerations for systems using the AA-E97900 RSN console server to connect to the Internet.

NOTE -

The AA-E99100 RSN console server is located inside the system cabinet. Therefore, Figure 1-1 does not apply to systems using the AA-E99100 RSN console server.

Figure 1-1. AA-E97900 RSN Console Server Connections (Internet)



Figure 1-2 shows cabling considerations for systems using the AA-E99100 RSN console server to connect to a modem.



Figure 1-2. AA-E99100 Console Server Connections (Modem)

Figure 1-3 shows cabling considerations for systems using the AA-E97900 RSN console server to connect to a modem.





Site Planning Checklist

Referring to the information in this document, answer the following questions:

Do you have a telephone and telephone line near the operator's station for voice communications when calling for support?

Planning for RSN Connectivity

- □ If using the AA-E99100 console server to connect to the Internet, do you have an Ethernet connection to the Internet and do you have OpenVOS Release 18.0.0 or later installed?
- □ If using the AA-E97900 console server to connect to the Internet, do you have an Ethernet connection to the Internet and do you have OpenVOS Release 17.1.0 or later installed?
- □ If using the AA-E99100 or AA-E97900 console server to connect to a modem, do you have an external telephone line available for the RSN modem?

NOTE _____

A dedicated phone line for the RSN modem provides the most reliable service. RSN calls routed through a PBX may be slow due to load on the PBX, or may not complete successfully due to disconnections. If you must use a PBX, do not route the telephone extension through a switchboard; instead, provide a direct-dial analog number.

Planning for Optional Components

❑ The system contains two embedded 10/100/1000 megabits-per-second (Mbps) Ethernet ports. Will your system additionally include any of the following PCI adapters for network communications? If so, in Table 1-1, indicate the total number of ports, and plan network connections for all Ethernet ports you will use.

Table 1-1.	Ethernet	PCI	Adapters
------------	----------	-----	----------

Adapter	Total Number of Ports
U582V Quad-Port Gigabit Ethernet Adapter	4
U583V Quad-Port Fiber Gigabit Ethernet Adapter	4
U584V Dual-Port 10 Gigabit Ethernet Adapter	2

Do you have a system PC console located at the installation site? Plan to keep the console located with the system.

□ To plan for storage enclosures in your system, see the *Stratus ftServer Systems: Peripherals Site Planning Guide* (R582) for descriptions of the enclosures and the names of the required PCI adapters.

Planning AC Power

- □ Have you selected and purchased two UPS units for each ftServer system?
- □ What optional components will you use?
- U What are the HVAC and AC power requirements of all optional components?
- □ What are the lengths and types of the power cords that are provided for the optional components?
- □ What type of AC receptacles do you need to provide?
- □ Is the AC power service wired properly?

Planning Space for Your System

- □ Will your system and its external components fit where you plan to place them?
- □ What are the lengths and types of the interface and communications cables that will connect to your system?
- Have you created a sketch of how you plan to arrange the system at the installation site? Consider the available cable lengths, the placement of external devices, and the location of network and voice communication connections.

On the sketch, show the following:

- Location of the system and its external components
- Power cords, and telephone and interface cables
- Locations of AC power receptacles, phone jacks, Ethernet jacks, switches, and hubs

NOTICE -

Make sure that all cords and cables are long enough to reach between their respective components and connectors. Route all cables out of the way of foot traffic.

Working with Other Groups

- □ Have you provided your facilities group and contractors with the sketch of how you plan to arrange the system and copies of the following?
 - "Redundant Power Sources" on page 3-1
 - Appendix B, "Electrical Circuit and Wiring Information"
 - Any notes you have about site planning

Have you reviewed and discussed the requirements with the facilities personnel and contractors to ensure that all site modifications are understood and implemented?

If you have any questions about the number and types of components, contact your Stratus account executive or distributor.

Preparing to Install a System

To prepare for the installation of a system by a field engineer, perform the following tasks:

- 1. Complete all site preparation work, as described in "Preparing to Take Delivery of a System" on page 1-9.
- 2. Take delivery of the system.
- 3. Move the system to its installation site, as described in "Moving the System to the Installation Site" on page 1-10.

Preparing to Take Delivery of a System

Before you take delivery of your system, perform the following tasks:

- 1. Secure traffic permits for the delivery vehicle and security clearances for moving the shipping container within your facility if necessary.
- 2. Determine a suitable delivery site with enough space for unloading the system.
- 3. Make sure that the delivery site will accommodate the delivery vehicle.

NOTE _____

Depending on the system configuration and the components you have ordered, a separate carton containing components may be shipped with your system.

When your system arrives, perform the following tasks:

- Contact the CAC or your authorized Stratus service representative.
- Check the Shockwatch sensors to determine if they have been activated. If a sensor has been activated, or if there is any damage, report it immediately to the carrier and to the CAC or your authorized Stratus service representative.
- Check the packing list. If you received the wrong shipment, or if the shipment is incomplete, report it immediately to the carrier and to the CAC or your authorized Stratus service representative.

Moving the System to the Installation Site

Before moving your system to the installation site, perform the following tasks:

NOTE _____

Moving a system requires two able-bodied persons.

- 1. Obtain a pallet jack to move your system from the delivery area to the installation site.
- 2. Check the dimensions of doorways and the load capacities of floors and elevators. You should walk the path over which you will move the system to ensure that it can be easily moved to the installation site. If your system will not fit through the doorways, you may need to arrange for rigging.

NOTE
Each cabinet is shipped on a pallet that is slightly larger
than a standard door opening. A standard door opening is
35 in. (89 cm) wide, and all pallets are 41.0 in. (104.2 cm)
wide by 53.0 in. (134.6 cm) deep.

- 3. If you are moving the system across a raised floor, lay plywood on the raised floor to prevent floor tiles from popping up when you move the system.
- 4. Move the system as close to the installation site as possible.

System Documentation

Table 1-2 lists the hardware documents for ftServer V 6512 systems, and the tasks described in each document.

Table 1-2. ftServer V 6512 System Documentation	(Page 1 of 2)
-------------------------------------------------	---------------

Document	Task
Stratus ftServer V Series Systems: PCI Adapter Guide (R679)	Install, configure, replace, or troubleshoot PCI adapters
Stratus ftServer Systems: Peripherals Site Planning Guide (R582)	Find information about optional equipment that you have ordered with your system that is needed to complete site preparation
Stratus ftServer V 6512 System: Site Planning Guide (R675)	Prepare a site for installation of your ftServer system

Document	Task	
Stratus ftServer V 6512 System: Operation and Maintenance Guide (R674)	Start up, shut down, and operate your system	
	Troubleshoot system hardware	
	Remove and replace CRUs, including PCI adapters	
Read Me First: Moving ftServer V 6512 Systems to the Installation Site (R676)	Inspect and unpack ftServer system hardware	

Table 1-2. ftServer V 6512 System Documentation (Page 2 of 2)

Safety Notices



WARNING -

Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions provided with the battery.



WARNING

If you receive locking power cords with your system, do not substitute other power cords. Use of the locking power cords ensures proper grounding of the system.



WARNING –

The system uses two power cords to provide redundant sources of power. To fully remove power from a system, disconnect both power cords. To reduce the risk that electrical shock could injure a person or damage the system, exercise caution when working in the unit even when only one power cord is connected.



WARNING —

To prevent a cabinet from tipping over and injuring a person or damaging the system, start installing systems from the bottom of the cabinet upward.



WARNING -

If you replace the modem cable supplied by Stratus, use a cable with a gauge of at least 26 AWG to prevent fire.



To avoid fire, electric shock, and equipment breakdown, prevent water or foreign objects from getting into the equipment. Do not let water or foreign objects, such as pins or paper clips, enter the equipment.



WARNING -

To prevent fire or current leakage, do not plug the power cord into a nonconforming outlet. Use a power outlet with appropriate voltage and power type, as specified in this guide.



WARNING

Do not install the equipment where you may need an extension cord. Use of an extension cord that does not meet the power specifications introduces a risk of overheating that could lead to a fire.



WARNING

Disconnect the power cords from the server or power source before you install or relocate the equipment. All voltage is removed only when the power cords are disconnected.



WARNING

Do not install or store the equipment in an unsuitable place. Install or store the equipment in a place that meets the requirements specified in this guide. Avoid the following conditions to avoid the risk of fire:

- Dust
- High humidity, such as a place near a boiler
- Direct sunlight
- Instability, such as places not stabilized against earthquakes



WARNING —

Do not use or store this product in a corrosive environment.

Avoid using or storing this product in an environment which may contain corrosive gases. Such gases include, but are not limited to, sulfur dioxide, hydrogen sulfide, nitrogen dioxide, chlorine, ammonia or ozone.

Avoid installing this product in a dusty environment or one that may contain corrosive materials such as sodium chloride or sulfur.

Avoid installing this product in an environment which may contain excessive metal flakes or conductive particles in the air.

Such environments may cause corrosion or short circuits within this product, resulting in not only damage to this product, but also fire.

If there are any concerns regarding the environment at the planned site of installation or storage, please contact your CAC or your authorized Stratus service representative.



WARNING -

When installing a system or CRU, always connect the power cord first, before adding communications cables. The power cord contains the protective earth connection; it should be connected first and disconnected last, to maintain a grounded chassis.

Before attempting to remove a CRU from the system chassis, make sure to power off the CRU, disconnect communications cables, and then disconnect the power cord.

Never connect a power cord to a CRU when it is not located within the system chassis.



WARNING -

Do not disassemble, repair, or alter the server, except as described in the operation and maintenance guide for your system. There is a risk of an electric shock or fire as well as equipment malfunction if you do not observe the instructions in the operation and maintenance guide for your system.



WARNING

Do not place any object on top of the server. The object may fall off and cause injuries, damage to hardware, or a fire.



WARNING

Do not leave the DVD tray ejected. Dust may enter the equipment and cause it to malfunction. The ejected tray may also become a cause of injuries.

Consignes de sécurité



AVERTISSEMENT —

Risque d'explosion si la batterie est remplacée par une autre de type incorrect. Jeter les batteries usagées conformément aux instructions fournies avec la batterie.



AVERTISSEMENT -

Si vous recevez des cordons d'alimentation dotés d'un système de verrouillage, n'utilisez pas d'autres cordons d'alimentation. L'utilisation de cordons d'alimentation dotés d'un système de verrouillage garantit une mise à la terre correcte du système.



AVERTISSEMENT -

Le système utilise deux cordons d'alimentation pour fournir des sources d'alimentation redondantes. Pour mettre un système entièrement hors tension, débrancher les deux cordons d'alimentation. Pour réduire le risque qu'un choc électrique puisse blesser une personne ou endommager le système, utiliser l'unité avec prudence même lorsqu'un seul cordon d'alimentation est branché.



Pour éviter qu'une armoire ne bascule et blesse une personne ou endommage le système, commencer par installer les systèmes de bas en haut de l'armoire.



AVERTISSEMENT -

Si vous remplacez le câble du modem fourni par un câble Stratus, utilisez un câble avec un calibre d'au moins 26 AWG pour éviter un incendie.



AVERTISSEMENT —

Pour éviter tout risque d'incendie, de choc électrique et de panne de matériel, empêcher l'eau ou les objets étrangers d'entrer dans l'équipement. Ne pas laisser d'eau ou d'objets étrangers, tels que des agrafes ou des trombones, entrer dans l'équipement.



AVERTISSEMENT -

Ne pas installer l'équipement dans un lieu où une rallonge pourrait être nécessaire. L'utilisation d'une rallonge ne respectant pas les spécifications électriques présente un risque de surchauffe pouvant provoquer un incendie.



AVERTISSEMENT ———

Débrancher les cordons d'alimentation du serveur ou de la source d'alimentation avant d'installer ou de déplacer l'équipement. Toute la tension n'est coupée que lorsque les cordons d'alimentation sont débranchés.



AVERTISSEMENT -

Ne pas installer ou entreposer l'équipement dans un lieu inadapté. Installer ou entreposer l'équipement dans un lieu qui satisfait aux exigences spécifiées dans ce guide. Eviter les situations suivantes pour empêcher le risque d'incendie :

- Poussière
- Forte humidité, comme à proximité d'une chaudière
- Exposition directe au soleil

 Instabilité, comme des endroits non stabilisés contre les tremblements de terre



AVERTISSEMENT -

Ne pas utiliser ou entreposer ce produit dans un environnement corrosif.

Éviter d'utiliser ou d'entreposer ce produit dans un environnement qui pourrait contenir des gaz corrosifs. Ces gaz incluent, mais sans s'y limiter, du dioxyde de soufre, du sulfure d'hydrogène, du dioxyde d'azote, du chlore, de l'ammoniac ou de l'ozone.

Éviter d'installer ce produit dans un environnement poussiéreux ou qui pourrait contenir des matériaux corrosifs, tels que du chlorure de sodium ou du soufre.

Éviter d'installer ce produit dans un environnement qui pourrait contenir des éclats de métal excessifs ou des particules conductrices dans l'air.

Ces environnements peuvent causer une corrosion ou des cours-circuits dans ce produit, ce qui endommage non seulement le produit, mais peut aussi provoquer un incendie.

Pour toute question concernant l'environnement sur le site planifié de l'installation ou de l'entreposage, veuillez communiquer avec votre centre d'assistance à la clientèle (CAC).



AVERTISSEMENT -

Lors de l'installation d'un système ou d'une unité remplaçable par le client (CRU), commencez toujours par brancher le cordon d'alimentation, avant d'ajouter les câbles de communications. Le cordon d'alimentation est équipé d'une connexion de terre de protection; il doit être branché en premier et débranché en dernier afin de conserver un châssis relié à la terre. Avant d'essayer d'enlever une CRU du châssis du système, veillez à bien mettre la CRU hors tension, à débrancher les câbles de communications, puis à débrancher le cordon d'alimentation.Ne jamais brancher un cordon d'alimentation à une CRU lorsqu'elle n'est pas à l'intérieur du châssis du système.



AVERTISSEMENT ------

Ne pas démonter, réparer ni modifier le serveur, sauf comme décrit dans le manuel d'utilisation et d'entretien de votre système. Il existe un du manuel risque d'électrocution ou d'incendie ainsi qu'un risque de dysfonctionnement de l'équipement si vous ne respectez pas les instructions d'utilisation et d'entretien de votre système.



AVERTISSEMENT ------

Ne placer aucun objet au-dessus du serveur. L'objet pourrait tomber et causer des blessures, endommager le matériel ou provoquer un incendie.



AVERTISSEMENT ——

Ne pas laisser le plateau du DVD ouvert. De la poussière pourrait entrer dans l'équipement et causer une défaillance. Le plateau d'éjection pourrait également causer des blessures en position ouverte.

安全注意事項



若錯誤更換電池類型,將產生爆炸風險。請按電池包裝 說明,妥善丟棄已耗廢電池。



系統採用兩條電源線,以提供冗餘電源。欲徹底清除系 統電源,先拔下兩條電源線。為降低觸電所導致的人體 傷害或系統損害,請小心操作機體,即使系統僅插入一 條電源線。 • WARNING ------

欲預防儲櫃翻倒,進而導致人體傷害或系統損害,請從 儲櫃下方開始往上安裝系統。



若您更換由Stratus供應的數據機纜線,請使用至少有26 AVG壓力的纜線,避免發生火災。



避免火災、觸電、設備故障、液體或其他異物進入設 備。不得譲液體或類似圖釘或迴紋針等異物進入設備。



為避免火災或漏電,不得將電源線插入規格不符的的插 座中。請使用本指南指定之電壓及電源類別的的插座。



不得使用延長線安裝設備。使用與指定電源規格不符的 延長線會產生設備過熱風險,進而可能導致火災。



安裝或移動設備前,請從伺服器或電源拔下電源插頭。

只有在拔下電源線後,設備的所有電壓才會消除。



不得在不適合場所安裝或存放設備。請按本指南指定且 符合規格要求的場所安裝或存放設備。避免下列可能產 生火災風險的地方:

灰塵較多 熱水器旁濕氣較重的地方 陽光直照的地方 不平穩位置,例如易受地震影響的地方



不得在腐蝕性環境中使用或存放產品。避免在含腐蝕性 氣體的環境使用或存放本產品,其中包括但不限於:二 氧化琉、氫化琉、氮、氫、氨或臭氧。

不得將本產品安裝在灰塵較多或含類似氯化鈉或硫磺等腐蝕性物質的地方。

不得將本產品安裝在空氣中含過量金屬碎片或傳導粒子 的地方。

上述環境可能導致本產品腐蝕或短路,因而損壞產品, 甚至引起火災。若對產品安裝或存放的場地環境規劃有 任何疑問,請與CAC或授權Stratus服務代表聯絡。 / WARNING _____

不得在伺服器已連接電源的狀態下連接界面電纜。安裝 或移除任何內建裝置,或從伺服器拔下或連接任何界面 電纜前,確認已關閉伺服器的電源,並從伺服器或電插 座拔下電纜線。即使伺服器電源已切斷,在仍連接電源 的狀態下,碰觸內建裝置、電纜或連接器也可能產生觸 電、或因短路而引起火災。



除非按照系统操作和维护指南的说明,不能拆卸、修理 或者改装服务器。如果您不遵守系统操作和维护指南的 说明,会有触电或者火灾以及设备故障的风险。|



不得在伺服器上放置任何物件。物件可能會掉落而導致 人體傷害、硬體損壞或火災。



DVD光碟機不得靜置於彈出位置。灰塵進入設備將導致 功能異常。彈出的光盤也可能是導致設備損壞的來源。

Chapter 2 AC Power Planning

This chapter describes the AC power requirements of ftServer V 6512 systems. It contains the following sections:

- "AC Power Overview" on page 2-1
- "Redundant Power Sources" on page 2-1
- "AC Power and HVAC Worksheets" on page 2-2
- "Selecting a UPS Unit for ftServer Systems" on page 2-4
- "Main Cabinet Ground Cables" on page 2-6

AC Power Overview

For fault tolerance, each ftServer system requires two separate and independent AC power sources. These power sources feed two UPS units. The UPS units feed power to power distribution units (PDUs) inside the main cabinet that, in turn, distribute power to the system's components.

You can use one of the UPS models that Stratus has qualified. See "Selecting a UPS Unit for ftServer Systems" on page 2-4 for more information.

You must also provide AC power to the system PC console, RSN console server, and RSN modem (if present) located outside the main cabinet.

Redundant Power Sources

Each ftServer system requires two separate and independent AC power sources: an *A-side* power source and a *B-side* power source. Because either side must be capable of continuing to provide power if power to the other side is lost, each power source must provide uninterruptible AC power.

Each PDU receives power from its power source and distributes power to the components inside the cabinet.

The top PDU (or if mounted vertically the left PDU when viewed from the rear) in the cabinet receives power from the A-side power source and distributes power to the following components:

- The A-side CPU-I/O enclosure
- The A-side of the optional network I/O enclosure
- One side of each disk storage enclosure that is installed in the system cabinet
- The A-sides of the supported Ethernet and Fibre Channel (FC) switches

The bottom PDU in the cabinet receives power from the B-side power source and distributes power to the following components:

- The B-side CPU-I/O enclosure
- The B-side of the optional network I/O enclosure
- One side of each disk storage enclosure that is installed in the system cabinet
- The B-sides of the supported Ethernet and FC switches

AC Power and HVAC Worksheets

When planning for the system's electrical needs, consider the following:

- The AC power service required at the site
- The cooling required to service dissipated power
- Power cord lengths, plug types, and current rating

This section contains the following worksheets:

- Table 2-1, a site planning worksheet for determining the number and types of AC outlets required at the site and the lengths of the power cords.
- Table 2-2, a worksheet for site AC power and HVAC requirements.

For each row in Table 2-1:

- Fill in the Quantity of Product Purchased column.
- Multiply it by the supplied value in the No. of AC Outlets Required column.
- Write the result in the Subtotal of AC Outlets column.
- Determine the total number of AC outlets by adding the values in the **Subtotal of AC Outlets** column.

Table 2-1. Worksheet for Planning Site	AC Outlets and Cord Lengths
----------------------------------------	-----------------------------

Product Purchased	Quantity of Product	No. of AC Outlets Required	Subtotal of AC Outlets	Type of Plug	AC Cord Lengths
ftServer V 6512	_	_	0 [†]	NEMA L6-20P or hardwired to UPS AC output terminals. [‡]	15 ft. (4.5m)
UPS units (two for each ftServer system)		x 1 =		Hardwire to site AC power source.	Provided by customer.
Total AC connectors					

† All ftServer components plug into PDUs in the main cabinet. Each PDU receives power from a UPS unit.

‡ See the Peripheral Equipment Available from Third Parties web page for more information.

In Table 2-2, determine the watts of AC power required by the system and its BTU output. For each row:

- Fill in the **Quantity** value and multiply it by the supplied **Watts** value.
- Write the result in the Watts Subtotal column.
- Determine the total number of watts of AC power required by adding the values in the **Watts Subtotal** column.
- Multiply each entry in the **Watts Subtotal** column by 3.41 and enter the number of BTUs in the **BTUs/hr. Subtotal** column.
- Determine the total number of BTUs per hour by adding the values in the **BTUs/hr. Subtotal** column.

Product Purchased	Quantity	Watts	Watts Subtotal	Convert to BTUs	BTUs/hr. Subtotal
ftServer V 6512 systems		x 3100 [†] =		x 3.41 =	
RSN console server		x 35 [‡] =		x 3.41 =	
AA-E97900 RSN console server		x 12 =		x 3.41 =	
RSN modem		x 4 =		x 3.41 =	
Optional network I/O enclosure (fully loaded)		x 750 =		x 3.41 =	
Optional tape enclosure		x 215 [§] =			
Total BTUs/hr.					
Total watts					

Table 2-2. Work Sheet for Site AC Power and HVAC Requirements

† For the maximum configuration of an ftServer V 6512 system consisting of two CPU-I/O enclosures, six fully populated ftScalable Storage trays, two Ethernet switches, and two FC switches.

[‡] This value represents the **highest** wattage consumed by supported RSN console servers. See the *Stratus ftServer Systems: Peripherals Site Planning Guide* (R582) for the wattage consumption of your specific RSN console server.

§ This value represents the **highest** wattage consumed by supported tape enclosures. See the *Stratus ftServer Systems: Peripherals Site Planning Guide* (R582) for the wattage consumption of your specific tape enclosure.

Selecting a UPS Unit for ftServer Systems

Each 38U system cabinet uses two UPS units: one to supply power to the A-side power distribution system and one to supply power to the B-side. Stratus does not sell or service UPS units. However, Stratus has qualified UPS models for use with ftServer V 6512 systems. To select an appropriate UPS model and purchase it directly from the UPS vendor, see:

http://stratadoc.stratus.com/genref/refsell/qualified_equipment.html
AC Power Connections to Qualified UPS Models

Use only AC power cords specified by Stratus for the UPS-to-PDU AC power connections. For a complete list of approved power cords, see Table 2-3. For information about recommended UPS models, see the following:

- The Peripheral Equipment Available from Third Parties web page
- The documentation supplied with your UPS

Table 2-3.	Power	Cords	for	ftServer	Systems
------------	-------	-------	-----	----------	---------

Marketing ID	Plug Types	Rating	Length	Locale
B50154F	IEC 60320 C19 to IEC 60309	16A/250V	15 ft (4.5m)	International
B50171F	IEC 60320 C19 to NEMA L6-20P	16A/250V	15 ft (4.5m)	North America UL approved
B50175	IEC 60320 C19 to L6-20P	20A/250V	15 ft (4.5m)	Japan PSE approved



A qualified electrician must supply and hardwire the UPS AC input cord, and if required an AC output cord, distribution panel, or conduit to each UPS unit in compliance with local and national electrical code.



AVERTISSEMENT -

Un électricien qualifié doit fournir et relier le câble d'entrée CA de l'onduleur, et si besoin, un câble de sortie CA, un panneau de distribution ou un conduit à chaque système d'onduleur, conformément au code électrique local et national.



WARNING — — —

Place all power cords out of the way of foot traffic.



AVERTISSEMENT -

Éloigner tous les cordons d'alimentation du passage.

Main Cabinet Ground Cables

Table 2-4 provides information about the main cabinet ground cable.

Table 2-4. Main Cabinet Ground Cable

Component	Cable Description	Stratus PN	Length
Cabinet ground leakage cable	10AWG ground leakage cable with 1/4 in. (6.35 mm) and M8 ring lugs	AW002000	15 ft (4.6m)

Chapter 3 Space Planning and Component Location

This chapter describes the space and location requirements for an ftServer V 6512 system and its external components. As you plan the site, make sure that you locate external components so that all cords and cables between them and the system can reach their connection points.

This chapter describes the requirements for the following connections:

- "RSN Connections" on page 3-1
- "Fibre Channel Connections" on page 3-2
- "UPS Connections" on page 3-2
- "Component Location and Cabling Summary" on page 3-3
- "Room Requirements" on page 3-5
- "Creating a Floor Plan" on page 3-7

RSN Connections

ftServer V Series modules require a connection to the Remote Service Network (RSN), which allows the CAC or your authorized Stratus service representative to remotely diagnose, troubleshoot, and resolve problems online. The connection to the RSN is implemented through an *RSN bridge module*, which is a module that is physically connected to the Internet or a modem (a dialup connection). The RSN bridge module provides connectivity to the RSN for both itself and other modules in the same system.

Stratus provides and installs the RSN console server and related components.

When the RSN console server connects to a modem, in addition to the telephone line (which you must supply), the modem and console server use serial and Ethernet cables, which Stratus provides and installs. See "Component Location and Cabling Summary" on page 3-3 for more information about RSN cable requirements.

For additional information, see the following manuals:

- OpenVOS System Administration: Administering and Customizing a System (R281) for information on processes, files, and commands required for RSN support.
- Stratus ftServer V 6512 System: Operation and Maintenance Guide (R674) for detailed information on RSN console servers and RSN modem connections.
- OpenVOS System Administration: Configuring a System (R287) for information on the devices.tin file entries that OpenVOS requires for an RSN connection through a modem.

Fibre Channel Connections

ftServer V 6512 systems support connections to ftScalable Storage G2 RAID controller enclosures through optical FC host bus adapters (HBAs) in the CPU-I/O enclosures. Stratus installs and connects ftScalable Storage G2 systems as follows:

 ftServer V 6512 systems connect to ftScalable Storage G2 RAID controller enclosures through a U581V 20-Port Fabric Switch.

The U580V PCI adapters are dual-ported. For connections to ftScalable Storage G2 RAID controller enclosures, ports are teamed in pairs for fault tolerance.

For more information on FC connections, see the following manuals:

- Stratus ftServer Systems: Peripherals Site Planning Guide (R582) for information about the supported PCI adapters.
- *ftScalable Storage G2: Getting Started Guide* (R651) for information about connecting to ftScalable Storage G2 systems.
- Stratus ftServer Systems: PCI Adapter Guide (R461) for information about the adapters Stratus supplies for your ftServer system.

UPS Connections

For management of UPS units, each UPS unit connects to a different Ethernet switch. You must supply Ethernet cables to connect the management card of each UPS unit to its Ethernet switch (two cables). See "Maintenance Network" on page 4-3 for information about the Ethernet switches.

Stratus provides a PDU AC input cord for each UPS unit. See "Component Location and Cabling Summary" on page 3-3 for more information.

Component Location and Cabling Summary

Although many of the cords and cables are provided by Stratus, you must provide certain cord and cables. Table 3-1 summarizes the cords and cables you need to be aware of for site planning purposes and whether Stratus provides them or not.

Component	Cord or Cable Type	Source	Description
AA-E99100 RSN console server	Ethernet cable (1)	Provided by Stratus	RSN console to system - 7 ft. (2.10m)
	Serial cable (1)	Provided by Stratus	RSN console to system - 10 ft. (3.10m)
With an AA-C72100 modem	Serial cable (1)	Provided by Stratus	RSN console to modem - 6 ft. (1.83m)
AA-E97900 RSN console server	Ethernet cable (1)	Provided by Stratus	RSN console to system - 20 ft. (6.10m)
	Serial cable (1)	Provided by Stratus	RSN console to system - 25 ft. (7.62m)
With an AA-C72100 modem	Serial cable (1)	Provided by Stratus	RSN console to modem - 6 ft. (1.83m)
AA-C72100 modem	Telephone cord (1)	Customer supplied	Modem (RJ-11) to service jack. Ensure that cord is long enough to reach telephone service jack. See "Telephone Lines" on page 4-1 for more information.
UPS (2)	AC power cord (2)	Provided by Stratus	UPS output to system PDU input - 15 ft. (4.57m)
	Ethernet (2)	Customer supplied	Ensure that cables are long enough to reach from UPS units to Ethernet switches in system cabinet.
PC Console	Ethernet cable (1)	Provided by Stratus (optionally customer supplied)	PC console to system Ethernet port - 6ft. (1.83m). Provide your own cable if a longer cable is required.
	Serial cable (1)	Provided by Stratus	PC console to system COM port - 25 ft. (7.62m)

 Table 3-1. Cord and Cable Summary (Page 1 of 2)

Table 3-1.	Cord and	Cable Summary	(Page 2 of 2)
------------	----------	---------------	---------------

Component	Cord or Cable Type	Source	Description
Telephone	Telephone cord (1)	Customer supplied	Ensure that the cord is long enough to reach from the telephone service jack to the telephone near the PC console.
Optional available Ethernet ports (embedded or PCI adapter)	Ethernet cable (1 for each optional port used)	Customer supplied	Ensure that cables are long enough to reach from site Ethernet port, hub, or switch. Cable type varies depending upon the type of Ethernet adapter. See the <i>Stratus</i> <i>ftServer Systems: PCI Adapter</i> <i>Guide</i> (R461) for specific cable requirements.
Optional U760 Eight-Port Serial Synchronous PICM G 2.16 Adapter (in optional NIO enclosure)	RS-232C, RS-449, or V-35	Provided by Stratus	Optional NIO enclosure to network connection - 12ft. (3.65m)

The lengths of supplied cords and cables dictate the maximum distance between the ftServer V 6512 system and its external components. Table 3-2 summarizes these constraints.

Table 3-2. Location	of V Series System	Components (Pag	e 1 of 2)
---------------------	--------------------	-----------------	-----------

Component	Location of Component	External Component Location
AA-E99100 RSN console server	Located inside the system cabinet	N/A
AA-E97900 RSN console server	Free standing, located outside the system cabinet	Place within 9 feet of system (length of Ethernet cable minus vertical runs)
AA-C72100 RSN modem	Free standing. Typically located near the system cabinet	Place close to the RSN console server
UPS (2)	Typically located outside the system cabinet	Place within 8 feet of system (length of PDU AC input cords minus vertical runs)

Component	Location of Component	External Component Location
PC Console	Located outside the system cabinet on a table or other suitable surface	Place immediately next to system (length of Ethernet cable minus vertical runs)
Telephone	Typically located near PC Console	Typically place within 17 feet of system
Optional U760 Eight-Port Serial Synchronous PICMG 2.16 Adapter	Inside NIO enclosure rackmounted in system cabinet	Place network connection points within 4 feet of system (length of adapter hydra cables minus vertical runs)

Table 3-2. Location of V Series System Components (Page 2 of 2)

Room Requirements

To ensure that the installation site provides a properly equipped, cooled, and sized environment, make sure that the site:

- Is a computer room
- Provides clearances for air circulation, opening cabinet doors, removing cabinet panels, and servicing the system from the front and rear.

Locate the front and rear of the system at least 2.5 feet (ft) (0.76 meters (m)) from walls and other obstructions.

• Maintains reasonable temperature and humidity levels and has a thermometer and humidistat to monitor room temperature and humidity.

See Chapter 2, "AC Power Planning" for detailed information about HVAC planning and Appendix A, "System Specifications" for detailed information about temperature and humidity requirements.

• Is as free of dust as possible of airborne contamination (particulate and gaseous).

NOTICE	·
Due to the centers ho	mission-critical nature of Stratus servers, data using the equipment should follow the
guidelines	of airborne contamination (particulate and
gaseous) a	is outlined in the ASHRAE (TC) 9.9
documenta	tion. Particulate matter to adhere to ISO
14644-1 CI	ass 8. Gaseous contamination, such as sulfur
or chlorine-	bearing gases to adhere to
ANSI/ISA-7	71.04-1985 Severity level G1.

Dust buildup in the system can impede air circulation and heat transfer, causing components to become less reliable as the ambient temperature rises.

Fans clogged by dust fail to expel hot air, causing circuit boards to overheat and fail.

Dust on circuit boards raises the temperature, thus reducing the component's mean time between failure (MTBF).

Dust circulating in the room increases the risk of fire within the room by providing potential combustible material within the environment.

- Has sufficient floor space for external components.
- Provides a table or desktop for external devices such as a telephone, RSN console server, RSN modem (if present), and a system PC console.

You cannot place these peripheral components in or on top of a system cabinet.

- Allows the system and peripheral devices to be placed within the room so that power cords and communications cables will reach their respective power receptacles, telephone jacks, and other connection points.
- Provides communications cable connectors or patch panels as needed.
- Provides two electrically separate grounded AC circuits to connect to the UPS units
- Provides grounded AC wall outlets for external components that do not connect to a PDU.
- Provides cutouts in the floor for routing cables, if the site has an elevated floor.
- Contains space for future expansion.

NOTICE _____

Do not place the system in an area of high electrostatic discharge. Static electricity may damage components. Do not locate components near transformers or other electromagnetic devices.

See Appendix A, "System Specifications" and Stratus ftServer Systems: Peripherals Site Planning Guide (R582) for the dimensions of system components.

Figure 3-1 illustrates the space-planning considerations. You must provide a flat surface for the AA-E97900 RSN console server and the RSN modem (if present).

NOTE -----

The AA-E99100 RSN console server is located inside the system cabinet, not on an external flat surface.



Figure 3-1. Space-Planning Considerations

Cabinet Mounting and Leveling Considerations

The main cabinet has cabinet-leveling feet. Anti-tip brackets are optional. The cabinet-leveling feet and the anti-tip brackets rest on top of the floor, so you do not need to drill holes in the floor.

Creating a Floor Plan

This section provides equipment templates and a site-layout grid to help you plan the placement of the components within the room. Appendix A, "System Specifications" provides detailed specifications for each of the system's components.

Figures 1-1, 1-2, and 1-3 illustrate a typical layout for the system cabinet, storage cabinet, UPS units, and system PC console.

Use the equipment templates in Figure 3-2 and the site-layout grid in Figure 3-3 to create a floor plan of the installation site for your ftServer system. On this floor plan, sketch the:

- Locations of the system and all external components
- Locations and types of AC power outlets
- Lengths and routes of power cords
- · Locations of phone jacks, Ethernet jacks, switches, and/or hubs
- · Lengths and routes of telephone and other communications and interface cables

NOTE	

Make sure that all cords and cables are long enough to reach between their respective components and connectors. Route all cables out of the way of foot traffic.

Figure 3-2 contains the equipment templates to be used in the site-layout grid.

The site-layout grid in Figure 3-3 represents a room measuring 20 ft. by 25 ft. (6 m by 8m). Note that the minimum room size for the core system components is 8 ft. by 8 ft. (2.6m by 2.6m). The scale of Figure 3-3 is 1/4-inch (0.64 cm) equals 1 foot (30.5 cm).

In Figure 3-3, trace the outline of the room in which the ftServer system will be located. Then, photocopy and cut out the templates in Figure 3-2 and arrange them to represent your ftServer configuration in the outline of the room. The equipment templates are drawn to the same scale as the grid page.





NOTES -

- 1. Figure 3-2 shows possible locations of the AA-E97900 RSN console server. The AA-E99100 RSN console server is located inside the system cabinet and therefore does not need to appear in your floor plan.
- 2. The shading on the templates indicates the access area required for servicing.

Figure 3-3. Site-Layout Grid



Chapter 4 Other Infrastructure Requirements

This chapter describes other infrastructure requirements, including telephone, Ethernet networks, and the system PC console. It contains the following sections:

- "Telephone Lines" on page 4-1
- "Network Connections" on page 4-2
- "System PC Console" on page 4-4

Telephone Lines

You must provide one telephone and one or two telephone lines at your site:

- You must have one telephone and line that is reserved for making voice service calls. The telephone should be placed such that it can be used by a person who has access to the PC console, the front of the system, and the back of the system.
- When using an RSN console server with an RSN modem, you must supply an additional telephone line to connect to the modem. You must supply a sufficiently long telephone cable that has an RJ-11 connector on the end that connects to the modem.

ΝΟΤΕ	E
------	---

To provide the most reliable service for RSN connections, use a dedicated phone line for the modem. RSN calls routed through a PBX might be slow, due to the load on the PBX, or might not complete successfully because the calls can become disconnected. If you must use a PBX, do not route the telephone extension through a switchboard; instead, provide a direct-dial analog number. For additional information, see the following manuals:

- OpenVOS System Administration: Administering and Customizing a System (R281) for information on processes, files, and commands required for RSN support.
- Stratus ftServer V 6512 System: Operation and Maintenance Guide (R674) for detailed information on modem connections.
- OpenVOS System Administration: Configuring a System (R287) for information on the devices.tin file entries that OpenVOS requires for an RSN connection through a modem.

Network Connections

The following sections provide site-planning information for networks:

NOTICE ____

Make sure network cables can be routed out of the way of foot traffic.

- "Site Ethernet Networks" on page 4-2
- "Ethernet Subnet Requirements" on page 4-3
- "Maintenance Network" on page 4-3

Site Ethernet Networks

For connections to one or more optional Ethernet site networks, you must provide the following:

- Site Ethernet ports, hubs, or switches
- Ethernet cables

You connect a site network to the ftServer system using any available Ethernet ports in the embedded adapters or in supported Ethernet PCI adapters. See Table 1-1 for a list of supported adapters.

NOTE _____

Two Ethernet ports are typically paired and teamed in software for fault tolerance. Each member of the pair requires an Ethernet cable. For information on teaming the Ethernet ports in software, see the *OpenVOS STREAMS TCP/IP Administrator's Guide* (R419).

ftServer V 6512 systems also support separate class C Ethernet subnets for various system components, as described in "Ethernet Subnet Requirements" on page 4-3.

Ethernet Subnet Requirements

ftServer V 6512 systems require separate Class C Ethernet subnets. Table 4-1 lists the subnet requirements for different system configurations.

System Configuration	Separate Class C Ethernet Subnets
ftServer system with an optional network I/O enclosure	One subnet in the form 10.10.1. <i>X</i> to connect the host system to the maintenance network's Ethernet switches. See "Maintenance Network" on page 4-3 for more information.
	A second subnet in the form $10.20.1.X$ to connect the host system and the network I/O enclosure.
	Additional subnets to connect the host system to site networks
ftServer system without an optional network I/O enclosure	One subnet in the form 10.10.1. <i>X</i> to connect the host system to the maintenance network's Ethernet switches. See "Maintenance Network" on page 4-3 for more information.
	Additional subnets to connect the host system to site networks

 Table 4-1. Ethernet Subnet Requirements

Maintenance Network

The CAC or other authorized Stratus service representative uses a maintenance network for remote service and debugging of components in ftServer V 6512 systems. The maintenance network connects the following components either to two U780 12-Port Ethernet Switches or to two U772 24-Port 10/100 Ethernet Switches:

- ftScalable Storage G2 RAID controller modules
- U581V 20-Port Fabric Switch
- RSN console server
- UPS units
- System PC console

NOTES —

1. The maintenance network is reserved for Stratus support and maintenance operations only. Do not connect other devices to it.

2. The U780 12-Port Ethernet Switch and U772 24-Port 10/100 Ethernet Switch are the only supported switches. You cannot use any other type of hub or switch in the maintenance network.

Stratus creates this network when installing the system and supplies the cables for it (except for the UPS Ethernet cables, which are customer supplied).

System PC Console

You must provide a PC with the following software and port to operate as the system PC console:

- The Microsoft[®] Windows[®] 7, Windows XP, or Windows Vista[®] operating system freshly installed
- A serial port or USB-to-serial port converter
- TinyTERM[®] terminal emulation software installed (Stratus provides this terminal emulation software)

Optionally, you can provide your own Ethernet cable if the provided six-foot long Ethernet cable is not long enough for your site (see Table 3-1).

See "Component Location and Cabling Summary" on page 3-3 for information about PC console cable requirements. See the *OpenVOS System Administration: Configuring a System* (R287) manual for information about how to configure the emulation software on the system PC console.

Chapter 5 Supported Configurations

This chapter contains information about supported cabinet configurations.

Cabinet Configurations

Figures 5-1 through 5-2 show the supported ftServer system cabinet configurations. The illustrations show the locations of components and filler panels.

Figure 5-1 illustrates an ftServer V 6512 system without the optional ftScalable Storage expansion trays or network I/O enclosure.





Figure 5-2 shows a fully configured ftServer V 6512 system that includes the optional ftScalable Storage expansion trays and network I/O enclosure.



Figure 5-2. Fully Configured ftServer V 6512 System

Appendix A System Specifications

For system specifications, see:

- "System Specifications" on page A-1
- "AAP87600V PDU Specifications" on page A-7

NOTES —

- 1. The system temperature and humidity requirements defined in Tables A-2 and A-3 are the **minimum** requirements the site must provide.
- 2. The temperature and humidity requirements for optional components are provided in the *Stratus ftServer Systems: Peripherals Site Planning Guide* (R582).

System Specifications

The following figures show front and rear views of the systems.

- Figure A-1 shows the front of a CPU-I/O enclosure pair in an ftServer system cabinet, with its bezel pulled forward.
- Figure A-2 shows the rear of a CPU-I/O enclosure pair in an ftServer system cabinet, specifying the locations of the connectors at the rear of the system.

Table A-1 lists the dimensions of the system cabinets. Table A-2 lists the specifications for the ftServer CPU-I/O enclosure and backplane assembly. The specifications in Table A-2 do not include information about other components, such as storage enclosures. See the *Stratus ftServer Systems: Peripherals Site Planning Guide* (R582) for the specifications of the other components.









PCIe adapter slot 3 (2) 1

2

6 Power supply LED (2)

8

9

- 7 Embedded 10/100/1000-Mbps Ethernet ports (4)
- PCIe adapter slot 4 (2) 3 PCIe adapter slot 1 (2)
- 4 PCIe adapter slot 2 (2)
- 5 Power receptacles (2)
- System backplane
- System backplane
- 10 Serial (COM) ports (2)

Table A-1. Cabinet Dimensions

2411 Shinning Container	
240 Shipping Container	
Height (including pallet)	56 in. (1.42m)
Width	41 in. (1.04m)
Depth	53 in. (1.35m)
38U Shipping Container	
Height (including pallet)	79.75 in. (2.03m)
Width	41 in. (1.04m)
Depth	53 in. (1.35m)
24U Cabinet	
Height (including casters)	50 in. (1.27m)
Width	27.5 in. (70 cm)
Depth	41 in. (1.04m)
Weight, empty	275 lb (125 kg)
Weight, empty with pallet and shipping container	436 lb (197.8 kg)
Weight capacity	1500 lb (559.9 kg)
38U Cabinet	
Height (including casters)	74 in. (1.9m)
Width	27.5 in. (70 cm)
Depth	41 in. (1.04m)
Weight, empty	344 lb (156 kg)
Weight, empty with pallet and shipping container	512 lb (232.2 kg)
Weight capacity	1500 lb (559.9 kg)

Table A-2. V 6512 System CPU-V O Enclosure: Specifications (Page 1 of 2)

Power			
Input power	700W for each enclosure (1400W total)		
Nominal input voltage	200-240VAC; 50/60 Hz		
Protective earth ground current	3.5 mA maximum for each AC power cord		
Physical Dimensions			
Height	7.0 in. (17.78 cm; 4U)		
Width	17.50 in. (44.45 cm)		
Depth	29.27 in. (74.34 cm), excluding rails and bezel		
Weight, including 12 DIMMS, 4 processors	Two enclosures, fully loaded: 84 lbs (38 kg) Rails and shelf unit: 13.8 lb (6.26 kg)		
Environmental			
Operating temperature	41° F to 95° F (5° C to 35° C) For every 800 ft (243.8 m) above 2000 ft (609.6 m), lower the maximum operating temperature by 1° C.		
Storage temperature	-38° F to 140° F (-40° C to 60° C), vented		
Operating altitude	0 ft to 10,000 ft (0m to 3,048m)		
Maximum rate of temperature change during operation	12° C per hour		
Relative humidity during operation	10% to 80% (noncondensing)		
Relative humidity during storage	5% to 95% (noncondensing)		
Heat dissipation, each system (both enclosures)	4777 BTUs per hour		
Air cleanliness	Meets ISO 14644-1 class 8 standards		
Features			
Processors	Two Intel Xeon Hex-Core 2.93 GHz processors in each CPU-I O enclosure		

Memory	12 physical, fully-buffered (FB) DDR3 inline memory module (DIMM) slots in each CPU-I O enclosure. All 12 slots are usable.
Ports	Two 10/100/1000-Mbps Ethernet ports in each CPU-I/O enclosure
	Two AC power connectors, one VGA port, two serial ports, and four USB ports† (three on the system backplane and one on the front panel)
PCIe slots	Two low-profile PCIe slots on the motherboard, 6.6 in (167.75 mm) maximum adapter length
Additional PCIe slots	 PCIe riser with two full-height-capable slots: Top riser slot (PCI 3): 7.7 in. (195.94 mm) maximum adapter length Lower riser slot (PCI 4): 6.6 in. (167.75 mm) maximum adapter length
BMC	One advanced system management module (Baseboard Management Controller, or BMC) embedded in each CPU- I O enclosure with one 10/100-Mbps Ethernet port dedicated to the BMC in each CPU-I O enclosure. BMCs include embedded Virtual Technician Module (VTM) functionality.
Disk drives	Up to eight Serial Attached SCSI (SAS) disks per CPU-I/O enclosure
DVD+/-R drive	DVD (+/-R Drive) in the front panel for installation of OpenVOS software and reads from CDs and DVDs

Table A-2. V 6512 System CPU-I/ O Enclosure: Specifications (Page 2 of 2)

AAP87600V PDU Specifications

The AAP87600V PDU, shown in Figure A-3, supplies power to ftServer systems and optional rack-mountable components.

Figure A-3. AAP87600V PDU



ssys108a

- 1 Power switch
- 2 Power receptacle

Table A-3 lists the specifications for the AAP87600V PDUs.

Table A-3.	AAP87600V	PDU: S	pecifications
------------	-----------	--------	---------------

Power	
Input power	N/A
Nominal input voltage; frequency	200–240 VAC; 50/60 Hz
Physical Dimensions	
Height	1.75 in. (4.45 cm)
Width	19.1 in. (48.51 cm)
Depth	6.75 in. (17.15 cm)
Environmental	
Operating temperature during operation	41° F to 95° F (5° C to 35° C) For every 800 ft (243.8m) above 2000 ft (609.6m), lower the maximum operating temperature (95° F (35° C)) by 1.8° F (1° C).
Maximum rate of temperature change during operation	12° C per hour or 0.2° C per minute
Relative humidity during operation	10% to 80% (noncondensing)
Storage temperature to 40,000 ft (12.2 km)	-38° F to 140° F (-40° C to 60° C)
Relative humidity during storage	5% to 95% (noncondensing)

٦

Appendix B Electrical Circuit and Wiring Information

For electrical circuit and wiring information that you need to provide to the contractor and/or facilities personnel responsible for wiring the power at the system installation site, see:

- "Fault Protection Requirements" on page B-1
- "Grounding Considerations" on page B-1
- "Circuit Wiring Diagrams" on page B-2
- "Electrical Power Connectors" on page B-8

Fault Protection Requirements

Each PDU in ftServer systems contains internal Transient Voltage Suppression (TVS) and overload protection. However, the system relies on the power distribution system at your site for protection against potential faults in the power cords and the wiring into the system base.

The pair of PDUs in the cabinet uses 20A or less circuit breakers in each power distribution branch that feeds the PDUs.

Grounding Considerations

The system obtains an earth reference ground through the power cords attached to the system. Similarly, each peripheral device connected to the system obtains ground through its power cord. For each peripheral device, you **must** ensure that a high-integrity safety-ground conductor is installed as part of the wiring system (in accordance with U.S. national electric code NFPA 70 or the equivalent). The international safety standard (EN60950) for electronic data processing (EDP) equipment also requires a ground conductor, but calls it a protective earth (PE) ground.

Depending upon local conditions, ground potentials may differ between the system base and any peripheral devices connected to the system base. All grounds in the system **must** return to the same reference point in the power distribution system, as close as possible to **zero (0) volt potential** relative to earth reference ground. Earth reference ground is typically a metal stake in the ground to which the ground conductors from one or more buildings are attached. As shown in Figure B-1, a *star ground* is often used to obtain the same earth reference ground. Each earth reference ground, such as the system base ground, is returned separately to a common point where a zero-volt (0V) earth ground exists. The star ground ensures that all equipment is at the same potential and that no noise or safety problems associated with an unpredictable or uncharacterized grounding system will occur.





- 1 To monitor
- 2 To ftServer system
- 3 Earth reference ground (0V)

Circuit Wiring Diagrams

The following circuit wiring diagrams show how the hot, ground, and/or neutral AC signals should be connected to the power input plugs of the system and optional components:

- Figure B-3 illustrates a single-phase 120V AC circuit connection.
- Figure B-4 illustrates a single-phase 240V AC circuit connection.
- Figure B-5 illustrates a split-phase 120/240V AC circuit connection.
- Figure B-6 illustrates a three-phase 208V AC, Y-, or Δ -source circuit connection, phase-to-phase.
- Figure B-7 illustrates a three-phase 380V AC, Y-, or Δ -source circuit connection, phase-to-neutral.

In the following diagrams, the power inputs for ftServer V 6512 systems are labeled X and Y, as shown in Figure B-2, to eliminate any ambiguities in the nomenclature. For single-phase applications, the X input is connected to the L (Line) *hot* input, and the Y

input is connected to the N (Neutral) input. However, for split-phase or three-phase applications, the X and Y inputs are connected to L1, L2, or L3 (separate lines). Therefore, for split-phase or three-phase applications, both X and Y can be electrically hot with respect to the system base (earth reference ground). Figure B-2 shows the physical locations of the X and Y inputs on the system PDU.



Figure B-2. Power Input Labeling

Figure B-3 shows a single-phase 120V AC circuit connection. Note that this application requires a single-pole circuit breaker.





Figure B-4 shows a single-phase 240V AC circuit connection. Note that this application requires a single-pole circuit breaker.





Figure B-5 shows a split-phase 120/240V AC circuit connection. Note that this application requires a double-pole circuit breaker.



Figure B-5. Split-Phase 120/240 Volts AC Circuit Connection

To power input A or B

Figure B-6 shows a three-phase 208V AC, Y-, or Δ -source circuit connection, which is a phase-to-phase source connection. Note that the X and Y inputs on the system can be connected from L1 and L2, L2 and L3, or L1 and L3. This application requires a double-pole circuit breaker.



Figure B-6. Three-Phase 208V AC, Y-, or D-Source Circuit Connection, Phase-to-Phase

To power input A or B

Figure B-7 shows a three-phase 380V AC, Y-, or Δ -source circuit connection, which is a phase-to-neutral source connection. Note that the system's X input can be connected to L1, L2, or L3. This application requires a single-pole circuit breaker.



Figure B-7. Three-Phase 380V AC, Y-, or D-Source Circuit Connection, Phase-to-Neutral

Electrical Power Connectors

 Table B-1 describes the connectors required by the AC power cords that Stratus supplies with ftServer systems.

Table B-1.	Connectors	for AC	Power	Outlets
------------	------------	--------	-------	---------

Connector	Configuration	Rating	Description
NEMA L6-20		20A, 250 volts AC	2-pole, 3-wire
IEC 60309 (formerly IEC 309)		16-20A, 250 volts AC	2-pole, 3-wire
Index

A

AC power, 2-1 requirements, 2-3 source, 2-1 worksheet, 2-2 anti-tip brackets, 3-7 A-side power source, 2-1

В

B-side power source, 2-1

С

cabinets, specifications, A-4 cables ground, 2-6 planning for, 1-3, 3-1 CAC, getting assistance, 1-2 checklist for site planning, 1-2 circuit, electrical planning information, B-1 wiring diagrams, B-2 communications cables planning for, 3-1 connectors, electrical, B-8 console. See RSN console server or system PC console cooling requirements, 2-2, 2-3 Customer Assistance Center. See CAC

Ε

earth reference ground, B-1 electrical connectors, B-8 electrical grounding, B-1 electrical wiring, B-1 environmental requirements maximum rate of temperature change, A-5 operating humidity, A-5 Ethernet subnet requirements, 4-3 Ethernet switches, 4-3

F

fault-tolerant systems, site planning, 1-2
floor plan, 3-7
ftScalable Storage systems

Fibre Channel connections, 3-2

ftServer systems

moving to the installation site, 1-10
preparing to install, 1-9
supported configurations, 5-1
taking delivery, 1-9

G

ground leakage cables, 2-6 grounding the system, B-1

Η

hubs, network, 1-3 HVAC worksheet, 2-2

I

IEC 60309 connector, B-8 installation site floor plan, 3-7 layout sample grid, 3-8 templates, 3-8 moving system to, 1-10 preparation, 1-9

J

jacks, Ethernet, 1-3

L

leveling feet, 3-7

Μ

main cabinet anti-tip brackets, 3-7 leveling feet, 3-7 maintenance network, 4-3

Ν

NEMA L6-20 connector, B-8

Ρ

PDUs, 2-2 AAP87600 site planning, A-7 specifications, A-8 specifications, A-8 power requirements, 2-3 protective earth ground, B-1

R

rack-mounted systems, A-1, A-5 removing power, 1-11 room requirements, 3-5 RSN connection, 1-3, 3-1 cables, 3-1 RSN console server, 1-3, 3-1 RSN dialup console server, 3-1 RSN modem, 1-3

S

safety, notices, 1-11 single-phase circuit connections 120 V AC, B-3 240 V AC, B-4 site planning checklist. 1-2 overview, 1-1 space planning cables. 1-3 future expansion, 3-6 room requirements, 3-5 specifications AP87600 PDUs, A-8 cabinet, A-4 CPU-I/O enclosure, A-5 split-phase circuit connections 120-240 V AC, B-5

star ground, B-2 Stratus Customer Assistance Center. See CAC supported configurations ftServer systems, 5-1 switches, site network, 1-3 system PC console, 1-2 requirements, 4-4

Т

technical support. See CAC telephone lines for support calls, 1-7, 4-1 terminal emulator, 4-4 three-phase circuit connections 208 V AC, B-6 380 V AC, B-7

U

uninterruptible power supply (UPS). See UPS

W

wiring, electrical, B-1 worksheets AC power, 2-2 HVAC, 2-2